

How to Check Blown Fuses and Capacitor Cells In Fixed Power Factor Correction Capacitors

Trouble: Fuse light is illuminated.

1. This indicates that a fuse is blown. Typically, power surges or a bad capacitor causes a fuse to blow.
2. **Disconnect power** from the capacitor unit and wait one minute after the power has been disconnected to allow capacitors to discharge.
3. Check affected capacitor following the steps below (*How to Test a Capacitor Cell*).
4. Replace affected fuse.

Trouble: Amber light is illuminated in KIM model PFCC

1. This may indicate that a fuse is blown or the capacitor has lost capacitance.
2. Check amperage draw of capacitor unit while it is connected to power based on the following table. If the amperage is low, complete the next three steps.

Applied Voltage	208 V	240 V	480 V	600 V
Amps/kVAr	2.78	2.41	1.20	0.96

1. **Disconnect power** from the capacitor unit and wait one minute after the power has been disconnected to allow capacitors to discharge.
2. Check the fuses using an ohmmeter. Replace any blown fuses.
3. Check the capacitors following the steps below (*How to Test a Capacitor Cell*)
4. Replace bad capacitor cells.

How to Test a Capacitor Cell

With a Capacitance Meter

Capacitor cells are rated in microfarad and voltage. The easiest way to test a cell is to measure the microfarads with a capacitance meter.

1. **Disconnect power** from the capacitor unit and wait one minute after the power has been disconnected to allow capacitors to discharge.
2. Measure microfarads using capacitance meter. The microfarads should be equal to the microfarad rating or up to 5% over the rating.
3. If microfarads are below the minimum, the cell is going bad.
4. Replace bad capacitor cells.

With a Capacitance Meter

If a capacitor meter is not readily available, the status of a cell can sometimes be determined visually.

1. If the cell can be “bulged out” or “pouched up” on the top, it is definitely bad.
2. **Disconnect power** from the capacitor unit and wait one minute after the power has been disconnected to allow capacitors to discharge.
3. Replace bad capacitor cells.

36825 Metro Court ♦ Sterling Heights, MI 48312

Toll Free: (800) 245-0583 | Phone: (586) 979-9955 | Fax: (586) 979-9484

www.myronzucker.com | info@myronzucker.com

POWER ♦ QUALITY